


FUNSKOOL

GIFT
SETFUN
Dough

INSTRUCTIONS

The Fundough Gift Set offers moulding and cutting fun like never before! With 12 different cutters there's no end to what you can create. The Crinkler is a clever little gadget which cuts textured patterns and designs in your Fundough and the Mini Fundough Extruder helps you create many different exciting shapes. With 5 tubs of Fundough, it is simply a super play set which provides endless hours of fun.


CONTENTS:




CUTTERS AND MOULDS



CRINKLER



DOUGH KNIFE

SHAPE MAKING
STRIPMINI FUNDOUGH
EXTRUDER

HOW TO USE THE CUTTERS:

- Flatten out Fundough on a smooth surface (See Fig.1).
- Choose any shape cutter and press it down on the Fundough (See Fig.2).
- Remove excess Fundough from around the shape cutter and then push out the character/object. (See Fig.3).



FIG.1




FIG.2



FIG.3

HOW TO USE THE CRINKLER:

- Flatten out Fundough on a smooth surface (See Fig.4).
- Roll either end of the crinkler over the Fundough (See Fig.5).
- Both ends of the crinkler have a different shaped groove on either side. Use the ends to create different designs with your Fundough. You can also use both ends along the same line or side-by-side to create new and interesting patterns.



FIG.4




FIG.5

HOW TO USE THE MINI FUN-DOUGH EXTRUDER:

- Slide the shape making strip into the front of the Mini Fundough extruder, positioning one of the shape slots at the centre of the extruder (See Fig.6).
- Lift the upper part of the extruder handle and place some Fundough into the cavity (See Fig.7).
- Slowly press the handle parts together to extrude the desired shape (See Fig.8).




FIG.6




FIG.7




FIG.8